


My Little Pony[®]

Dance 'n Prance Pony™

1. To make your pony dance, hold her tail and turn the flower-shaped brooch **clockwise** (see arrow in ILL. A). Wind the brooch until it is difficult to turn; **do not try to wind brooch beyond this point**. Place your pony on a flat surface, let go of her tail, and watch her dance as her tail twirls!

Note: **Do not** turn the brooch counterclockwise.



ILL. A