

On sunny days, Baby Tiddley-Winks™ likes to ride her swing high into the air outside the Lullabye Nursery! When it rains, she rides the swing indoors. To use outside:

- Snap awning cover into awning with bow facing up as shown. (ILL. 3)

- Attach awning under large window in back of Nursery by inserting hook into groove. Slide the two side tabs into slots.

To use indoors, hang assembled swing on hooks in the kitchen as shown. (ILL. 4)

To assemble mobile, insert pin into flat side of disc.

4. Pin will come through the square opening on the other side. Then, insert mobile disc into umbrella. (ILL. 5)

Hold pieces together with thumb and forefinger and snap into place. Hang mobile in Nursery by inserting pin into hole in ceiling. (ILL. 6).

Attach bottle shelf to kitchen wall by inserting tabs

5. on shelf into slots in wall. Place the two baby bottles and cereal bowl on shelf.







Splash, splash -- it's time for a bath! Insert the tabs on faucet into holes in the bathtub as shown. Place towel on towel rack in bathroom. (ILL. 7)

Attach gingham bow to Nursery by wrapping

6. elastic over baby-pin handle as shown. (ILL. 8)

7. To close, first swing the right side of the Nursery against the back section. Repeat on the left side. While holding the back of the Nursery, push the front door until all sections snap firmly into place.

Should the hinges detach, simply latch the bottom hinge into the bottom groove, the top hinge into the top groove and snap into place. (ILL. 9)



ILL. 1

ILL. 2

ILL. 4

ILL. 5

ILL. 6

ILL. 8

ILL. 3

ILL. 7

ILL. 9

NOTE: REMOVE SWING AWNING BEFORE REPLACING NURSERY IN THE BOX.

GROOVE

AWNING COVER

HINGE