




# Princess Baby Buggy™


## Instructions

Ages: 3 & Up


Remove all pieces from plastic bags and discard bags IMMEDIATELY.




1. Holding handle right side up as shown in illustration, slip hole in end of handle bar over post on front of buggy frame. Fit tab on lever into one of the 3 grooves in the handle bar. Snap remaining holes in handle bar over remaining post on buggy frame. You may have to gently squeeze handle to help hole snap over post.




2. Snap flowers onto posts on both ends of buggy handle.




3. With right side of wheel facing away from buggy, slip center hole in wheel over post on buggy base. Holding wheel in place, snap flower onto post. Repeat for remaining 3 wheels and flowers.




4. Stretch lace around top of basket and fit it into groove.




5. Place umbrella over large end of umbrella pole. Holding umbrella and pole together, insert tab on heart-shaped top into hole in umbrella and snap it into groove in umbrella pole.



6. Insert umbrella pole into slot in buggy. DO NOT attach it to buggy by pressing umbrella down as this may cause pole to bend.



7. Stretch and slip lace over umbrella and fit it into groove at edge of umbrella. Press tabs on edge of umbrella through lace. Tie shorter ribbon in a bow around heart-shaped top.



8. Buggy handle adjusts so ponies can "nuzzle" buggy along. To adjust handle, press lever beneath handle upward with your thumb. With your forefinger, move handle up or down until tab fits into one of the 3 grooves to adjust buggy to desired height.

